



## H3 BILLET FUEL DOOR

#H30080SC, SP

### PARTS LIST:

#1	BILLET FUEL DOOR
#2	SELF TAPPING SCREWS
#3	ADHESIVE TAPE KIT

### QTY:

1
2
1

### INSTALLATION:

- 1. CLEAN PLASTIC AREA:** It is important that the plastic area where the Billet Fuel Door will adhere to is very clean. Use rubbing alcohol or a product like Windex.
- 2. VERIFY POSITION:** Before removing the backing from the adhesive tape, hold the Billet Fuel Door in position on the vehicle so that it is level and verify the fit.
- 3. REMOVE BACKING FROM TAPE:** Remove the backing from the adhesive Tape.
- 4. POSITION, LEVEL, AND ATTACH:** With the fuel door closed, carefully place the Billet Fuel Door into position. **IMPORTANT: IT IS CRITICAL THE FUEL DOOR BE LEVEL AND SWINGS OPEN LEVEL WHEN INSTALLED. VERIFY THAT IT IS LEVEL BY CHECKING THE HINGE AND KEY LOCK ON THE FUEL DOOR. THE ADHESIVE TAPE IS VERY STRONG AND DIFFICULT TO REMOVE.**
- 5. INSTALL SCREWS IN TABS:** With the fuel door open, and the fuel cap removed, carefully screw in the self-tapping screws through the top and bottom stainless steel tabs into the plastic liner of the recessed area.
- 6. REPLACE FUEL CAP AND CLOSE FUEL DOOR.**