

#TU0000SC & TU0001SB TUNDRA BILLET FUEL DOOR

Application: '07-'08 Toyota Tundra

Please read and understand these instructions completely before installation to avoid any possible injury to yourself or the vehicle and/or accessory.

PARTS LIST:

DESCRIPTION:	QTY:
BILLET FUEL DOOR COVER	1
SETSCREW	1
FLAT WASHER	1

TOOLS REQUIRED:

FLAT BLADE SCREWDRIVER
ALLEN WRENCH
3/16" DRILL

INSTALLATION:

1. REMOVE STOCK FUEL DOOR: Open the fuel door and locate the locking tab. It might be covered by a factory sticker. Using a flat blade screwdriver pry the locking tab out slightly and pull the stock fuel door toward you sliding the stock fuel door off the door bracket. (See FIG 1 & 2)

2. DRILL SET SCREW HOLE: Drill a 3/16" hole for the set screw in the center of the area shown on the plastic backing plate. (See FIG 3)

3. INSTALL BILLET FUEL DOOR: Line up the lower tabs first, and then the upper tabs on the Billet Fuel Door with the slotted rails in the door bracket and slide the Billet Fuel Door on to the door bracket. The tab on the back of the Billet Fuel Door must slide past the locking tab on the door bracket. You will not be able to slide the Billet Fuel Door back off without releasing the locking tab if it is installed correctly. (See FIG 4)

4. ALIGN BILLET FUEL DOOR: Carefully close the fuel door to check front-to-back alignment. Be careful when first closing the Billet Fuel Door so you do not contact your paint. If the front side is too close to the body, slide the Billet Fuel Door slightly back to the rear of the truck until the Billet Fuel Door is properly aligned. (See FIG 5)

5. INSTALL SETSCREW: Using an allen wrench, install the setscrew with the flat washer provided to secure the Billet Fuel Door. (See FIG 6)

